



NOTES:

- CONCRETE PAD TO BE POURED INDEPENDENT OF OTHER CONCRETE WORK.
- CONTACT UNDERGROUND SERVICE ALERT 48 HOURS PRIOR TO INSTALLING BARRICADES. 1 (800) 642-2444 OR 811
- CONTACT CITRUS HEIGHTS WATER DISTRICT FOR REBAR INSPECTION PRIOR TO POURING CONCRETE AND PRIOR TO INSTALLING BARRICADES. (916) 725-6873
- MATERIALS BELOW AGGREGATE BASE SHALL BE COMPACTED TO 90% MINIMUM.
- REINFORCED CONCRETE PAD SHALL BE FINISHED WITH AN EDGING TOOL AROUND THE ENTIRE PERIMETER AND BROOMED AT RIGHT ANGLES TO THE DIRECTION OF TRAVEL.
- PAINT FIRE HYDRANT AND BARRICADES USING A RUSTOLEUM RECOMMENDED PRIMER, FINISH WITH RUSTOLEUM GLOSS WHITE, TWO COATS MINIMUM. PRIOR TO PAINTING, CLEAN ALL SURFACES WITH SOAP AND WATER USING AN ABRASIVE PAD.

1	REINFORCED CONCRETE PAD - TYPE II SIX-SACK PORTLAND CEMENT	5	72" x 6" SCH 40 STEEL PIPE FILLED WITH CONCRETE, TYPE II SIX-SACK PORTLAND CEMENT
2	3/8" (#3) REBAR - 2" INSIDE PERIMETER	6	12" DIAMETER HOLE FILLED W/ CONCRETE, TYPE II SIX-SACK PORTLAND CEMENT
3	CONCRETE DOBIE W/ WIRE	7	ASPHALT SATURATED ORGANIC FELT (ROOFING PAPER) - ASTM 30, 2 LAYERS AROUND FIRE HYDRANT
4	3/4" CLASS II AGGREGATE BASE - 2" MINIMUM, MECHANICALLY COMPACTED TO 90%		



# FIRE HYDRANT ACCESS PAD w/ BARRICADES

## CITRUS HEIGHTS WATER DISTRICT

APPROVED BY: Robert A. Churchill DATE: 5/8/13  
 CITRUS HEIGHTS WATER DISTRICT

DRAWN:	8 MAY 2013
REVISED:	
SCALE:	N.T.S.
DESIGN:	P.A.D.
CAD FILE:	FH_684.DWG
PAGE:	<b>FH_684</b>