



NOTES:

- CONCRETE PAD TO BE POURED INDEPENDENT OF OTHER CONCRETE WORK.
- CONTACT UNDERGROUND SERVICE ALERT 48 HOURS PRIOR TO INSTALLING BARRICADES. 1 (800) 642-2444 OR 811
- CONTACT CITRUS HEIGHTS WATER DISTRICT FOR REBAR INSPECTION PRIOR TO POURING CONCRETE AND PRIOR TO INSTALLING BARRICADES. (916) 725-6873
- MATERIALS BELOW AGGREGATE BASE SHALL BE COMPACTED TO 90% MINIMUM.
- REINFORCED CONCRETE PAD SHALL BE FINISHED WITH AN EDGING TOOL AROUND THE ENTIRE PERIMETER AND BROOMED AT RIGHT ANGLES TO THE DIRECTION OF TRAVEL.
- PAINT FIRE HYDRANT AND BARRICADES USING A RUSTOLEUM RECOMMENDED PRIMER, FINISH WITH RUSTOLEUM GLOSS WHITE, TWO COATS MINIMUM. PRIOR TO PAINTING, CLEAN ALL SURFACES WITH SOAP AND WATER USING AN ABRASIVE PAD.

1	REINFORCED CONCRETE PAD - TYPE II SIX-SACK PORTLAND CEMENT	5	72' x 6' SCH 40 STEEL PIPE FILLED WITH CONCRETE, TYPE II SIX-SACK PORTLAND CEMENT
2	3/8' (#3) REBAR - 2' INSIDE PERIMETER	6	12' DIAMETER HOLE FILLED W/ CONCRETE, TYPE II SIX-SACK PORTLAND CEMENT
3	CONCRETE DOBIE W/ WIRE	7	ASPHALT SATURATED ORGANIC FELT (ROOFING PAPER) - ASTM 30, 2 LAYERS AROUND FIRE HYDRANT
4	3/4' CLASS II AGGREGATE BASE - 2' MINIMUM, MECHANICALLY COMPACTED TO 90%		



**CITRUS
HEIGHTS
WATER
DISTRICT**

FIRE HYDRANT ACCESS PAD w/ BARRICADES

CITRUS HEIGHTS WATER DISTRICT

APPROVED BY:
Robert A. Churchill
CITRUS HEIGHTS WATER DISTRICT

DATE: *5/8/13*

DRAWN: 8 MAY 2013

REVISED:

SCALE: N.T.S.

DESIGN: P.A.D.

CAD FILE: FH_684.DWG

PAGE:

FH_684